


Instructions for Usin the Cherry Chomper

- 1) Insert Cherry into mouth of Cherry Chomper. Be sure to push the cherry beyond the tooth and all the way back into the Cherry Chomper.
- 2) Firmly push the head of the Cherry Chomper down all the way. The plunger will push the pit out of the cherry into the belly of the Cherry Chomper.
- 3) Poke your finger into the back of the Cherry Chomper's head and pop the cherry out of the front.



Cleaning

- 1) Pull off the 'pitbin' or belly of the Cherry Chomper, throw away the pits.
- 2) Both pieces of the Cherry Chomper are dishwasher safe.

Safety

- 1) Adult supervision is required at all times.